


Observables and Detectors




Project an image of the sky onto detector and record it

- telescope and instrument: optics, filters, detector
- stars, galaxies, all astronomical objects emit (or reflect, in the case of planets and asteroids) photons
- detectors converts photons into something we can measure, like volts or amps. We will use a detector called a “charged coupled device”, CCD for short. They convert one photon to one electron, regardless of the wavelength of the photon
 - other kinds of detectors: photographic film, bolometers, radio antennae
- Observe a source: measure the number of photons that arrive from our source and get converted into e- in each pixel. We record that information as a 2-dimensional array of the number of e- in each pixel, write it to a file
- Those measurements have uncertainty, statistical and systematic

A Charged Coupled Device (CCD)

Made of silicon, detect photons as red as 1 micron

Near-infrared detectors are similar, use different materials to match the lower-energy photons



Pixels give 2-d spatial information


We will come back to pixel size

Converts number of e- in each pixel to a voltage or current we can measure.
Adds Gaussian uncertainty “readnoise” to each pixel in the process.

Observables and Detectors

To use that image, we need to “process” or “reduce” it, and calibrate it

- measure and subtract the background contributed by the detector
- measure and subtract the sky background
- determine the fraction of photons from the source that were detected
- determine the uncertainty in the measurement of the number of photons from our source measured in each pixel



“Signal” = some source of e- (and therefore DN in your image) you are trying to measure

- from an astronomical source, it will usually be the number of photons/second

“Noise” = uncertainty in the estimate of that measurement. Could be uncertainty in the measurement of the astronomical object itself, or in the background you need to measure and subtract



Observables

Total power output from some source (like a star), energy per unit time (Watts).
An intrinsic property of the source.

Specific (per unit frequency) **Luminosity L_ν** : Energy per second per frequency interval

Total energy per unit time: $dE = L_\nu dt d\nu$

Sphere area A ,
distance R from the star.
Collect flux over all of A , get L_ν



We observe **Flux** (flux density), the fraction of the luminosity intercepted by our collector (telescope, antenna, your eye, etc.)

Flux F_ν ; units of ergs/sec/cm²/Hz


The SI unit of flux is the Jansky = 10^{-26} W/m²/Hz

$$dE = L_\nu dt d\nu = \int F_\nu dA = 4\pi R^2 F_\nu$$

Flux depends on distance from the source.

Standard Optical Filters

Johnson/Bessel UBVRI Filters



Used to define the range of wavelengths passed through to the detector and recorded in the image

Note x-axis, often defined as the “optical” region, UV cutoff to Si bandgap cutoff



Used to define the range of wavelengths passed through to the detector and recorded in the image

Observables

Magnitudes are measurements of flux:

$$m = -2.5 \log \frac{\int F_\nu S_\nu d(\log \nu)}{\int S_\nu d(\log \nu)} - zp$$

F_ν is the flux from the source

S_ν is the response function, e.g, a wavelength bandpass filter, the system sensitivity, etc. We almost always measure flux in a particular bandpass (wavelength range)

zp is the zero point, the calibration of the magnitude

We will talk more about magnitudes, magnitude systems and calibration later in the quarter

Observables

Radiation from a source with arbitrary shape and size: **specific intensity $I\nu$**
also "brightness" or "surface brightness"


$I\nu$ is the energy received per second, from a patch of angle on the sky, per unit collecting area, per frequency interval

Units: $\text{W/m}^2/\text{Hz/Sr}$ or $\text{ergs/cm}^2/\text{s/Hz/Sr}$

Sr = steradian, angle $d\Omega$

Usually measure surface brightness in magnitudes per square arcsec

$d\Omega$ integrated over a sphere is 4π



Observables

Example of specific intensity:
a blackbody

$$I_{\nu, Planck} = \left(\frac{2h\nu^3}{c^2} \right) \frac{1}{\exp h\nu/kT - 1}$$

Flux is specific intensity integrated
over solid angle of the source:

$$F_\nu = \int I_\nu \cos \theta d\Omega$$


$\cos \theta$ accounts for the
photon direction

For an unresolved point source, we measure flux


For an extended source, we can measure the flux per unit area, which is a surface brightness

Flux depends on distance from the source.

Surface brightness (intensity) does not, at least until cosmology changes the measurement geometry




Atmospheric absorption, optical and near-IR




Atmosphere transmission, Zenith. ESO Cerro Paranal

H₂O absorption bands
at $\lambda > 9000\text{\AA}$






Near Infrared Absorption

Atmospheric Transmission (1mm H₂O, Zenith)





And Near-IR emission, for comparison



Average annual transmission variation, zenith. ESO Cerro Paranal

One reason you have to take calibration data when you observe!



Noll et al. 2012


This figure shows transmission looking out through the atmosphere pointed at zenith.

As you point toward the horizon, your path length through the atmosphere increases.

More atoms and molecules to scatter and absorb light — transmission goes down


Approximate: $\text{airmass} = \sec z = \frac{1}{\cos z}$ where z is the angle of your line of sight, from zenith toward horizon

This is correct for a flat earth (!) and works well enough. You probably should not be observing where this approximation is not good!



Useful numbers:
airmass 2 = twice the path length through the atmosphere vs. zenith
airmass 2 is at zenith angle $z = 60$ degrees
(30 degrees above the horizon)

Atmosphere Emission, Zenith. ESO Cerro Paranal



Why do we describe observations by wavelength range? Changing sky brightness is one reason

Typical sky brightness, Mauna Kea, mag per square arcsec:

B 22.3

V 21.1

I 19.2

J 14.8

H 13.4

K 12.6 = few milli-Janskys arcsec⁻²

Sky brightness 10 magnitudes greater in K vs. B = 10,000x brighter in K than in B

Mid-IR 3.5 um (L-band): few Jy arcsec⁻²


20 um: ~1000 Jy arcsec⁻² (JWST!)


Far IR, few 100 microns: 100 Jy arcsec⁻²

1mm: few Jy arcsec⁻² (useful submm wavelength: 850 microns)


For a 1 arcsec source, the I-band sky magnitude integrated over the same aperture is 18
CFHT legacy survey limiting magnitude: 24.5
- 400x fainter than sky


Sky Brightness, New Moon









Night Sky Brightness, 90 degrees from the moon






Sky at new and full moon
as seen by the FORS2
spectrograph, ESO




ATMOSPHERIC TRANSMISSION VERSUS WAVELENGTH




CSO Atmospheric Transmission
Submillimeter

Mauna Kea, Hawaii (14,000 ft.)




Airglow time variability

Data from JCMT




Another reason to take calibration data: night sky variations!



A Charged Coupled Device (CCD)

Made of silicon, detect photons as red as 1 micron

Near-infrared detectors are similar, use different materials to match the lower-energy photons




Pixels give 2-d spatial information

We will come back to pixel size

Converts number of e- in each pixel to a voltage or current we can measure.
Adds Gaussian uncertainty “readnoise” to each pixel in the process.

- CCD collects e- in each pixel, output amplifier measures as volts
- Then convert that voltage to a number we can store
- 0 - Vmax (V_{max} = maximum value of voltage that can be measured)
 - also the maximum number of e- that can be measured in each pixel
- turn that into a set of discrete numerical values with an analog to digital converter
- Usually 16 bits = 65,535 discrete numerical values
 - steps are called **DN** = data numbers or **ADU** = analog-to-digital units
- $V_{max}/65535 = \text{volts/DN}$

$$\text{If } V_{max} = 5V: \quad 5V / 65535 \text{ DN} = 7.6 \times 10^{-5} \text{ V/DN}$$



What happens if the voltage on the CCD output is larger than 5V?

- detector system design choice: volts/DN and volts/e-
- user needs the **gain** of the detector system
 - measured in electrons/DN (or electrons/ADU)

Usually the gain gets measured by someone responsible for maintaining the instrument
 - should be available it in the documentation for the instrument, or you might have to measure it. We will use the documented values.