Often abbreviated as S/N or SN

Assume:

- photon counting detector
- not the same as integrating energy of arriving photons!
- sources of noise are independent, so they add in quadrature:

$$N_{total} = \sqrt{N_1^2 + N_2^2 + N_3^2 + \dots}$$

In the optical and shorter wavelengths, photon arrival obeys Poisson statistics

Probability of observing n photons in time t: Prob(n) = $\frac{(\lambda t)^n}{n!}e^{-\lambda t}$

For photon arrival rate λ , which is related to the flux from the object and the sensitivity of the system you are observing with.

Probability of observing n photons in time t: Prob(n) = $\frac{(\lambda t)^n}{n!}e^{-\lambda t}$


For photon arrival rate λ , which is related to the luminosity of the object and the sensitivity of the system you are observing with.

Even if you know λ perfectly, the distribution of the number of photons that arrive in time t will follow the Poisson distribution

How to reduce this uncertainty?


Measure N photons collected in many pixels to measure a uniform background, like the sky

Measure N photons in a pixel in many exposures of your source, or use a longer exposure time so N is larger



Signal to Noise ratio for an unresolved source:

$$\frac{S_{\gamma}t}{\sqrt{S_{\gamma}t+B_{\gamma}tA_{\Omega}+RN_{e-}^{2}N_{pix}}}$$



 $S_{\gamma}t$ = your signal, the number of photons from your source

Written as the product of the rate of photon arrival from the source S_{γ} in counts/second and the exposure time **t** you spent collecting the photons

Denominator is the "noise", the uncertainty in your measurement

- quadrature sum of the random noise processes that matters most for optical and NIR astronomy data. Adjust for radio, submm, other wavelengths
- does not include systematics, which can easily dominate any measurement error or uncertainty
 - examples: unknown gain, unstable bias or background,...

Signal to Noise ratio for an unresolved source:

$$\frac{S_{\gamma}t}{\sqrt{S_{\gamma}t+B_{\gamma}tA_{\Omega}+RN_{e-}^{2}N_{pix}}}$$

Green circle: source region

Source

Region of image dominated by background

N to collect

N total photons collected in the green circle is source plus sky plus dark current

 $S_{\gamma}t$ = your signal, N, the number of photons from your source

 $B_{\gamma}tA_{\Omega}$ = number of photons from the background in the source region

 $B_{\gamma}t$ = number of photons from the sky detected per square arcsecond in that region. Rate of photon arrival from the sky per square arcsecond B_{γ} times exposure time t.

This expression for signal to noise assumes you know B_{γ} perfectly


 A_{Ω} = area of source region, in square arcseconds (same sky units as B_{γ}).

Signal to Noise ratio for an unresolved source:

$$\frac{S_{\gamma}t}{\sqrt{S_{\gamma}t + B_{\gamma}tA_{\Omega} + RN_{e-}^{2}N_{pix}}}$$

Source

Region of image dominated by background



N total photons collected in the green circle is source plus sky plus dark current

 $S_{\gamma}t$ = your signal, the number of photons from your source, N_S

Written as the product of the rate of photon arrival from the source S_{γ} and the exposure time ${\bf t}$ you spent collecting the photons

You measure some number of counts in your source region N_{total} by adding up the counts in the green circle in the cartoon


Subtract an estimate of the background contribution by adding up the counts in a background region, the cyan circle in this cartoon.

Background estimate is $N_B = B_{\gamma} t A_{\Omega}$

Signal to Noise ratio for an unresolved source:

$$\frac{S_{\gamma}t}{\sqrt{S_{\gamma}t + B_{\gamma}tA_{\Omega} + RN_{e-}^{2}N_{pix}}}$$

Source
Region of image
dominated by background



N total photons collected in the green circle is source plus sky plus dark current

Propagation of the uncertainties: assume you only need to include the Poisson uncertainty in the number of photons you collect in your source region

 $S_{\gamma}t + B_{\gamma}tA_{\Omega} = N_{\text{total}}$ the total number of photons collected in the source region

$$\sqrt{S_{\gamma}t+B_{\gamma}tA_{\Omega}}$$
 is the Poisson uncertainty on N_{total}

That assumes you measure B_{γ} over a large enough area there is no additional uncertainty in your background estimate to include in the uncertainty on $S_{\gamma}t$. To make this assumption valid, you should use as large a region as you can to estimate the background. We will explore that in a homework and discuss.

Signal to Noise ratio for an unresolved source:

$$\frac{S_{\gamma}t}{\sqrt{S_{\gamma}t + B_{\gamma}tA_{\Omega} + RN_{e-}^{2}N_{pix}}}$$

Region of image dominated by background

N total photons collected in the green circle is source plus sky plus dark current

Some detectors generate their own background.

"dark current" is electrons that get a boost from thermal energy and are collected just like electrons that interact with astronomical photons

Same kind of measurement considerations apply: try to measure detector background rate well enough that you can neglect that source of uncertainty - impossible if that detector backgroud is not stable — beware!

Signal to Noise ratio for an unresolved source:

$$\frac{S_{\gamma}t}{\sqrt{S_{\gamma}t + B_{\gamma}tA_{\Omega} + RN_{e-}^{2}N_{pix}}}$$

Source
Region of image dominated by background

N total photons collected in the green

circle is source plus sky

plus dark current

Readnoise RN: uncertainty in the measurement of the signal in any pixel

- in photon counting detectors, units are electrons
- quantifies detector's (like a CCD or an IR detector) imperfect ability to measure the signal in any pixel
- NOT the same thing as uncertainty due to Poisson arrival statistics
- RN is per pixel. It contributes the quadrature sum of the contribution per pixel in your source region, assuming RN is the same for every pixel:

$$\sqrt{RN_1^2 + RN_2^2 + RN_3^2 + \dots + RN_N^2} = \sqrt{N_{pix} \times RN^2}$$

Signal to Noise ratio for an unresolved source:

e:
$$S_{\gamma}t$$

$$\sqrt{S_{\gamma}t + B_{\gamma}tA_{\Omega} + RN_{e-}^{2}N_{pix}}$$

Ways to improve SN:

Lower readnoise

- want source to occupy minimum number of pixels: fewer reads, more flux/pixel
- "minimum number of pixels" can only go so far
- this is what "binning" is for on detectors that can do it. Fewer reads per binned pixel
- read slower

Lower the dark current

- why you always hear about "filling dewars" and cryo-coolers

Read the detector slower (see next slide)

Reduce the sky background


- smaller $A_{\rm O}$ using adaptive optics
 - cool and baffle your instrument, go to space

Improve efficiency: collect more of the photons you get from the telescope

- anti-reflection coatings, better materials

Increase exposure time, take more exposures!

CCD Readout, Double Correlated Sampling



100 kHz = 1e5 Hz: time to read out 2048 x 2048 pixels = 42 seconds (or 1 4k x 4k CCD with 4 amplifiers)

One way to lower readnoise: average over current fluctuations in the output amplifier (and any other random noise)

Penalty: increased time to read each pixel to have time to average

Dark Current

of electrons in conduction band set by thermal distribution, $\sim \exp \frac{-E_{gap}}{kT}$

Density of states: at T=0 all electrons in states below the Fermi energy no electrons at higher energy

At larger temperatures, e- start to occupy nearby higher energy states At high enough temperatures, can get into conduction band

Density of e- in conduction band of Si at 300K: 1.38 x 10¹³ cm⁻³ at 77K (conveniently, the temperature of liquid nitrogen): 1.8 x 10⁻¹⁸ cm⁻³

This is not quite true for real Si, with impurities, but you get the idea. Cool your detector! IR detectors with smaller bandgaps have even bigger sensitivity to thermal e -> go colder!